


Types of thermodynamic processes

- **Adiabatic:** No heat transfer into or out of the system
- **Isobaric:** Pressure remains constant
- **Isochoric:** Volume remains constant
- **Isothermal:** Temperature remains constant
- **Ienthalpic:** Enthalpy remains constant
- **Isentropic:** A reversible adiabatic process where entropy remains constant
- **Steady state:** Internal energy remains constant

The first law:
 $\Delta U = Q - W$



$$PV^n = \text{Constant}$$

$\gamma = \frac{C_p}{C_v}$ is the heat capacity ratio.

Heat transfer during various processes (for an ideal gas),

① Isobaric: $\Delta P = 0$, $Q = n C_p (T_f - T_i) = n C_p (\Delta T)$
heat capacity at constant pressure

② Isothermal: $\Delta T = 0$, $\Delta U = 0$,
 $\Delta U = Q - W \Rightarrow Q = W$

(For ideal gas:
 $PV = nRT$)

③ Isochoric: $\Delta V = 0$, $\Rightarrow \Delta W = 0 \Rightarrow Q = \Delta U = n C_v (\Delta T)$
heat capacity at constant volume

④ Adiabatic: $Q = 0 \Rightarrow PV^\gamma = \text{Constant}$, with $\gamma = \frac{C_p}{C_v}$

Heat transfer during various processes (for an ideal gas)

① Isobaric: $\Delta P = 0$, $Q = n C_p (T_f - T_i) = n C_p (\Delta T)$
 \uparrow heat capacity at constant pressure

$PV = nRT$
 $W = \int p dv = P(V_f - V_i) \Rightarrow \Delta U = Q - W$
 change of Entropy: $\Delta S = \int \frac{dQ}{T} = \int_{T_i}^{T_f} n C_p \frac{dT}{T} = n C_p \ln\left(\frac{T_f}{T_i}\right)$
 Using $PV = nRT$
 $= n C_p \ln\left(\frac{V_f}{V_i}\right)$

② Isothermal: $\Delta T = 0$, $\Delta U = 0$,
 $\Delta U = Q - W \Rightarrow Q = W$

$W = \int p dv = \int \frac{nRT}{V} dv = nRT \ln\left(\frac{V_f}{V_i}\right)$

$\Delta S = \frac{Q}{T} = nR \ln\left(\frac{V_f}{V_i}\right)$

③ Isochoric: $\Delta V = 0$, $\Rightarrow W = 0$
 \uparrow heat capacity at constant volume

$\Rightarrow Q = \Delta U = n C_v (\Delta T)$

$\Delta S = \int \frac{dQ}{T} = \int_{T_i}^{T_f} n C_v \frac{dT}{T} = n C_v \ln\left(\frac{T_f}{T_i}\right)$

④ Adiabatic: $Q = 0 \Rightarrow PV^\gamma = C$ (a constant), with $\gamma = \frac{C_p}{C_v}$
 \uparrow

$W = \int p dv = \int \frac{C}{V^\gamma} dv = \frac{P_f V_f - P_i V_i}{1 - \gamma}$

$(C_p = C_v + R)$
 for ideal gas

$\Rightarrow \Delta U = Q - W = -W$

$\Delta S = \int \frac{dQ}{T} = 0$